NOTE: Please read all instructions carefully before using this product

Safety Notice

Hardware Identifier

Assembly Instruction

Parts List

Warranty

Ordering Parts

Model SR55


Retain This Manual for Reference

08-07-01

OWNER'S MANUAL



POWERHOUSE SQUAT RACK SR55



IMPEX FITNESS PRODUCTS 14777 DON JULIAN RD., CITY OF INDUSTRY, CA 91746 Tel: (800) 999-8899 Fax: (626) 961-9966 www.impex-fitness.com info@impex-fitness.com

TABLE OF CONTENTS

BEFORE YOU BEGIN	1
IMPORTANT SAFETY NOTICES	2
HARDWARE IDENTIFIER	3
ASSEMBLY INSTRUCTIONS	4
EXPLODED DIAGRAM	5
PARTS LIST	6
WARRANTY	7
ORDERING PARTS	7

BEFORE YOU BEGIN

Thank you for selecting the POWERHOUSE SQUAT RACK SR55 by IMPEX FITNESS PRODUCTS. For your safety and benefit, read this manual carefully before using the machine. As a manufacturer, we are committed to provide you complete customer satisfaction. If you have any questions, or find there are missing or damaged parts, we guarantee you complete satisfaction through direct assistance from our factory. To avoid unnecessary delays, *please call our TOLL-FREE customer service number.* Our Customer Service Agents will provide immediate assistance to you.

Toll-Free Customer Service Number 1-800-999-8899 Mon. - Fri. 9 a.m. - 5 p.m. PST www.impex-fitness.com info@impex-fitness.com

IMPORTANT SAFETY NOTICE

PRECAUTIONS

This exercise machine is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your machine. In particular, note the following safety precautions:

- 1. Keep children and pets away from the machine at all times. DO NOT leave children unattended in the same room with the machine.
- 2. Only one person at a time should use the machine.
- If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A PHYSICIAN IMMEDIATELY.
- 4. Position the machine on a clear, leveled surface. DO NOT use the machine near water or outdoors.
- 5. Keep hands away from all moving parts.
- 6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the machine. Running or aerobic shoes are also required when using the machine.
- 7. Use the machine only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
- 8. Do not place any sharp object around the machine.
- 9. Disabled person should not use the machine without a qualified person or physician in attendance.
- 10. Before using the machine to exercise, always do stretching exercises to properly warm up.
- 11. Never operate the machine if the machine is not functioning properly.
- 12. A spotter is recommended during exercise.


WARNING: BEFORE BEGINNING ANY EXERCISE PROGRAM, CONSULT YOUR PHYSICIAN. THIS IS ESPECIALLY IMPORTANT FOR INDIVIDUALS OVER THE AGE OF 35 OR PERSONS WITH PRE-EXISTING HEALTH PROBLEMS. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. IMPEX INC. ASSUMES NO RESPONSIBILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE SUSTAINED BY OR THROUGH THE USE OF THIS PRODUCT.

SAVE THESE INSTRUCTIONS.


HARDWARE IDENTIFIER

REPLACEMENT PARTS

PLACE WASHER, END OF BOLT, OR SCREW ON CIRCLE TO CHECK FOR CORRECT SIZE.



NOTE: When installing a Aircraft Nut (also called Nylon or Lock Nut), Please use two adjustable wrenches to tighten down the Nut. Hold down the Bolt with one wrench, and use the other wrench to turn the Nut clockwise.




ASSEMBLY INSTRUCTION

Tools Required to Assemble the Machine: Two Adjustable Wrenches and Allen Wrenches

NOTE: It is strongly recommended this machine to be assembled by two or more people to avoid possible injury.

STEP 1 (See Exploded Diagram)

- A.) Attach a base Frame (#19) to the end of Main Base Frame (#4). Secure it with one Bracket (#18), two M10 x 2 ¾" Carriage Bolts (#6), two Ø ¾" Washers (#9), and M10 Aircraft Nuts (#23). Repeat the same procedure to connect the other Base Frame (#19) on the other side.
- B.) Attach the Left Rear Vertical Frame (#12) to the Base Frame (#19). Align the holes to the Bracket (#18). Secure it with two M10 x 2 ¾" Carriage Bolts (#6), ؾ" Washers (#9), and M10 Aircraft Nuts (#23). Repeat the same procedure to install the other side.
- C.) Attach the Front Vertical Frame (#25) to the Base Frame (#19). Secure it with three M10 x 5/8" Allen Bolts (#8) and Ø ¾" Washers (#9). Secure the Front Vertical Frame (#25) to the Left Rear Vertical Frame (#12) with two M10 x 5/8" Allen Bolts (#8) and Ø ¾" Washers (#9). Repeat the same procedure to install the other side.
- D.) Attach one Diagonal Support (#5) to the Main Base Frame (#4). Attach the other end to the Rear Vertical Frame (#12). Secure the top and the bottom of the Diagonal Support (#5) with two M10 x 2 ¾" Carriage Bolts (#6), Ø ¾" Washers (#9), and M10 Aircraft Nuts (#23). Repeat the same procedure to install the other side.
- E.) Insert two Weight Holders (#13) into the two holes on the Rear Vertical Frame (#12). Secure each Weight Holder with one M10 x 1" Allen Bolt (#24) and Ø ¾" Washer (#9). Slide two Olympic Sleeves (#14) onto the Holders. Secure each Sleeve with a M8 x ½" Allen Set Screw (#16). Repeat the same procedure to install the other side.
- F.) Insert the Right & Left Bar Catches (#1) & (#20) into the selected holes on the Front Vertical Frames (#25).



PARTS LIST

KEY NO.	DESCRIPTION	Q'ty
1	Right Bar Catch	1
2	\varnothing 1" Bar Catch End Cap	2
3	Right Rear Vertical Frame	1
4	Main Base Frame	1
5	Diagonal Support	2
6	M10 x 2 ³ ⁄4" Carriage Bolt	12
7	Panel	2
8	M10 x 5/8" Allen Bolt	10
9	Ø ¾" Washer	26
10	M5 x 3/8" Philips Screw	6
11	2" x 2 ¾" End Cap	2
12	Left Rear Vertical Frame	1
13	Weight Holder	4
14	Olympic Sleeve	4
15	\varnothing 2" End Cap	4
16	M8 x ¹ / ₂ " Allen Set Screw	4
17	2" Square End Cap	4
18	Bracket	2
19	Base Frame	2
20	Left Bar Catch	1
21	2" Flat End Cap	2
22	Rubber Pad	2
23	M10 Aircraft Nut	12
24	M10 x 1" Allen Bolt	4
25	Front Vertical Frame	2



LIMITED WARRANTY

IMPEX Inc. ("IMPEX") warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of two years on the Frame from the date of purchase. This warranty extends only to the original purchaser. IMPEX's obligation under this Warranty is limited to replacing or repairing, at IMPEX's option.

All returns must be pre-authorized by IMPEX. Pre-authorization may be obtained by calling IMPEX Customer Service Department at 1-800-999-8899. All freights on products returned to IMPEX must be prepaid by the customer. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an IMPEX authorized service center or for products used for commercial or rental purposes. No other warranty beyond that specifically set forth above is authorized by IMPEX.

IMPEX is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or other damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyments or use, costs of removal, installation or other consequential damages or whatsoever natures. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you.

The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal right. You may also have other rights which vary from state to state. Register on-line at www.impex-fitness.com

IMPEX INC. 14777 Don Julian City of Industry, CA 91746

ORDERING REPLACEMENT PARTS

Replacement parts can be ordered by calling our Customer Service Department toll-free at **1-800-999-8899** during our regular business hours: Monday through Friday, 9 am until 5 pm Pacific standard time. **info@impex-fitness.com**

When ordering replacement parts, always give the following information.

- 1. Model
- 2. Description of Parts
- 3. Part Number
- 4. Date of Purchase